



Email us @ roe.graphics@yahoo.com or call us at 407-378-4000 Option 1

EMBLEM OVERLAY INSTALL/MUST BE ABOVE 65 DEGREES

WATCH VIDEO : Go to <https://www.roe-graphics.com/pages/installation-videos> and watch "Ford emblem overlay install" install video. If you make a mistake during install, contact us BEFORE removing any decals. Please watch other you tube videos on wet vinyl installation procedures to familiarize yourself or contact us with any questions.

1. Clean desired surface with a non- oil based cleaner and a lint free cloth such as a microfiber cloth. Be sure to remove any flaking paint left on emblem

2. **WATCH VIDEO**

3. **DO NOT** use too much soap—DO NOT expose decals to wind, rain or car washing for at least 24 hours

4. **KEY POINTS:** Start with smaller emblem, clean surface, wet area and decal, use heat source to conform decal, allow overlay to dry **BEFORE** applying FORD lettering. If you follow these instructions and take your time you will have no bubbles.

NOTE: As long as the decals are wet they can be adjusted a few times. Once a heat source is applied it is permanent. Allow adhesive to set for a couple days to assure adhesion before washing. Feel free to message us with any questions. We value our perfect feedback score on eBay and would like to keep it. We understand install can be difficult and recommend professionals. If you attempt yourself and mess it up, **message us before leaving feedback.**