



## Fender Hash Installation directions- Without Application tape

Each stripe is labeled on back of backing paper. Application tape cannot be used on 5th Gen Camaros due to curved surfaces

### Required Tools:

- Spray bottle of Rapid Tac or soap/water mixture
- New, SHARP exacto Knife
- Microfiber cloth
- Felt Squeegee

**WATCH VIDEO** BEFORE ATTEMPTING INSTALL. Dont judge us, the videos are from when we were poor veterans starting a business. Watch video at <https://www.youtube.com/watch?v=sxTRswOdGHg>. If you make a mistake during install, contact us BEFORE removing any decals.

**NOTE:** Trim bottom edge under wheel well as close as possible to metal surface.

**DO NOT ALLOW DECALS TO STICK TO PLASTIC AREA.** Do not allow your finish point to be on the plastic. Trim to wrap on the shell of the vehicle only. Removal of tire may be required, or just turning the wheels to the side.

**NEVER use hard plastics on vinyl surface.** Only use a microfiber cloth or felt squeegee.

**NOTE:** If you are installing **PIN STRIPED** fender hashes follow these steps for pin striping after completing install of double hash.

1. Dry area, then remove pin stripe from backing. Use second person to assure decal doesn't get stuck to anything.
2. Start at top and run stripe down outside edge. Be sure to keep spacing equal.
3. Trim excess the same as large hashes.

As long as the decals are wet they can be adjusted a few times. Once a heat source is applied it is permanent.

Feel free to message me with any questions. We value our perfect feedback score on eBay and would like to keep it. We understand install is difficult and recommend professionals. If you attempt yourself and mess it up, message us before leaving feedback.

Email us @ [roe.graphics@yahoo.com](mailto:roe.graphics@yahoo.com) or call us at 407-378-4000 Option 1