



## Large Decal Installation direction/MUST BE OVER 65 DEGREES

WATCH VIDEO: These instructions are for you to reference. Please watch videos on website @ [www.roe-graphics.com](http://www.roe-graphics.com). If you make a mistake during install, contact us BEFORE removing any decals. The video above is of decals WITH application tape. Please forgive our unprofessional videos, we were poor veterans when we made them.

**DO NOT INSTALL MIRROR CHROME OR MATALIC CARBON FIBER DECALS WET. USE DRY HINGE METHOD (SEE VIDEO)**

**IT MUST BE ABOVE 65 DEGREES AND NOT WINDY. DO NOT INSTALL IN DIRECT SUNLIGHT.**

1. Look through videos on website [www.roe-graphics.com/installation-videos](http://www.roe-graphics.com/installation-videos). Some are very specific to certain decals but others are universal. If you purchased a rather large decal with installation tape then "Large Decal" and "Large Decal Hinge Method" videos will work best. If you purchased any other specialty decals like fender hash, side vents, or engine decals please watch associated videos. If you have any questions or cannot find a video that explains your install, please call us or email us (Listed Below)

2. WATCH VIDEO: Use a friend if necessary and do not install in windy conditions.

3. Clean desired surface with a non oil based cleaner (Dawn) and a lint free cloth such as a microfiber cloth. To remove all road Grime we would suggests you claybar wash the area(s) first, then wash away wax with Dawn. If there is any wax on the area, decals will not adhere.

4. Use a mixture of dish soap and water in a spray bottle. Small amount of soap (just a drop or two). Spray the desired install area liberally.

5. Remove Decal From Vinyl Backing.

6. Spray the adhesive side of decal as well, lay the decal down, align, and smooth out bubbles and water using hands, Credit Card or Squeegee.

7. Once decal is smoothed down. Use a hair dryer or a heat gun to finish. Use squeegee to work remaining bubbles to the edges while applying heat in a back and forth sweeping motion. Never hold heat in one spot for a long time. When you feel the decal is dry, test one corner to see if vinyl stays down as application tape is removed. When you are ready to remove application tape, wet application tape thoroughly and then peel it away.

8. Now that Application tape has been removed you may see some bubbles. Using a Felt Squeegee or a Credit card wrapped in a microfiber cloth, work out bubbles to the nearest edge. **NEVER apply hard plastic directly to vinyl.**

9. If your decal requires trimming, use a very sharp exacto knife or razor blade. Trim with enough access to wrap under surface. Do not allow vinyl to wrap under and stick to anything except metal surfaces.

**NOTE:** As long as the decals are wet they can be adjusted a few times. Once a heat source is applied it is permanent. Allow adhesive to set for a 24h 48 hours or more to assure it sets before washing. Feel free to message us with any questions. Installation can be difficult and we recommend professionals. If you attempt yourself and mess it up, message us before leaving feedback. We may be able to help you!

Email us @ [roe.graphics@yahoo.com](mailto:roe.graphics@yahoo.com) or call us at 407-378-4000 Option 1